



Cocaine Hydrochloride & Cocaine Free-Base

(powder & crack)

Drug Detection Training

C34 Wipes
(ONE-PART POUCH)



C34 // OVERVIEW



WHAT CAN C34 WIPES DETECT

- cocaine

WHAT FORMS CAN C34 WIPES TEST

- powders, pills, liquids, residues, trace, and bulk

COLOR-CHANGING TECHNOLOGY

- When C34 comes in contact with cocaine free-base (crack), or others, it turns sky blue/light blue to indicate cocaine, or its analogues, is present
- Positive result color will match the box color



Note: The Trace-Eye-D kit is intended to be used for **presumptive identification purposes only**, and all substances tested should be subjected to more definitive examination by scientists in a properly equipped crime laboratory.

C34 // HOW TO USE



Open. Wipe. Look.

Reduce cross-contamination and exposure to C34, test surfaces and samples by wearing industry-standard personal protective equipment (PPE) such as nitrile gloves, eye protection, and N95 mask equivalent.

1

OPEN the pouch and remove the wipe. Do not unfold towelette before or after use. Doing so will result in difficulty observing the results.

2

WIPE it across the surface to be tested. For best results, sample very small amounts of the substance on the margin of the wipe.

3

LOOK to see if the formula on the wipe changes color. Allow up to 30 seconds for a color reaction to develop.

- negative result // no color change
- positive result // test turns pink/magenta



C34 // RESULTS



Open. Wipe. Look.

NEGATIVE Result
no color change



POSITIVE Result
test turns sky blue/light blue



C34 // POST TEST



Open. Wipe. Look.

All TRACE EYE-D products are safe for disposal in the common waste stream without neutralization or other special treatment, provided the wipe is not contaminated with drug residue

- 1** **PHOTOGRAPH + STORE** the wipe with a date/time stamp, if required for evidence retention, as the color of the wipe may change over time.
- 2** **DISPOSE** of wipe in accordance with federal state and local environmental laws. No neutralization is required. Can be disposed of in the common waste stream.
- 3** **WASH HANDS + CHANGE** your gloves before conducting additional tests after a positive result is found.

Interested in additional training for your team?



[BOOK A LIVE TRAINING SESSION NOW](#)