

Chlorate Oxidizer Explosive Detection Training

CO40 Wipes
(TWO-PART POUCH)

CO40 // OVERVIEW



WHAT CAN CO40 WIPES DETECT

- chlorates

WHAT FORMS CAN CO40 WIPES TEST

- powders, pills, liquids, residues, trace, and bulk

COLOR-CHANGING TECHNOLOGY

- When CO40 comes in contact with chlorates, it turns deep purple



Note: The Trace-Eye-D kit is intended to be used for **presumptive identification purposes only**, and all substances tested should be subjected to more definitive examination by scientists in a properly equipped crime laboratory.

CO40 // HOW TO USE



Open. Wipe. Look.

Reduce cross-contamination and exposure to CO40, test surfaces and samples by wearing industry-standard personal protective equipment (PPE) such as nitrile gloves, eye protection, and N95 mask equivalent.

- 1** **To activate**, fold bottom portion of pouch in half. Squeeze folded portion until you hear a "pop" sound. Work the fluid from upper chamber to lower chamber.
OPEN the pouch and remove the wipe. *Do not unfold towelette before or after use.* Doing so will result in difficulty observing the results.
- 2** **WIPE** it across the surface to be tested. For best results, sample very small amounts of the substance on the margin of the wipe.
- 3** **LOOK** to see if the formula on the wipe changes color. Allow up to 30 seconds to allow a color reaction to develop
 - negative result // no color change
 - positive result // test turns deep purple

**If testing a suspected substance that is suspended in an oily base (e.g. RDX in petroleum jelly), a delay in the results may be experienced. The medium in which the explosive/oxidizer is suspended will delay results.*

CO40 // RESULTS




Open. Wipe. Look.

NEGATIVE Result
no color change



POSITIVE Result
test turns deep purple



CO40 // POST TEST



Open. Wipe. Look.

All TRACE EYE-D products are safe for disposal in the common waste stream without neutralization or other special treatment, provided the wipe is not contaminated with explosive residue

- 1** **PHOTOGRAPH + STORE** the wipe with a date/time stamp, if required for evidence retention, as the color of the wipe may change over time.
- 2** **DISPOSE** of wipe in accordance with federal state and local environmental laws. No neutralization is required. Can be disposed of in the common waste stream.
- 3** **WASH HANDS + CHANGE** your gloves before conducting additional tests after a positive result is found.

Interested in additional training for your team?



BOOK A LIVE TRAINING SESSION NOW