



TRACE EYE-D[®]



Peroxide Base

PB33

**EXPLOSIVE
DETECTION
WIPES**

**MADE
IN THE USA**

Detects: TATP, HMTD, MEKP, Urea
Peroxide.

TRACEEYED.COM

PB33

**EXPLOSIVE
DETECTION
WIPES**



Positive test result color

Directions | #OWLmethod

▶ **TO ACTIVATE**, fold bottom portion of pouch in half.
Squeeze folded portion until you hear a “pop” sound.
Work the fluid from upper chamber to lower chamber.

▶ **OPEN** pouch and remove wipe.

Do not unfold towelette before or after use - doing so may result in difficulty observing the results.

▶ **WIPE** it across the surface to be tested.

For best results, sample small amounts of the substance on the outer edge of the wipe.

▶ **LOOK** to see if the wipe has changed color.

Most results are instant, however, some may take up to 30 seconds for a color reaction to develop.

- Negative Result: NO color change
- Positive Result: Dark Purple