



TRACE EYE-D®

W42

Cannabinoids

(Delta 8, 9, 10, THC & CBN)

Drug Detection Training



W42 Wipes

(TWO-PART POUCH)



RESULTS
IN SECONDS



TRUSTED BY
LAW ENFORCEMENT



OPEN. WIPE. LOOK.
#OWLmethod



MADE IN USA



trace-eye-d.com



866.872.2391



info@traceeyed.com

#OWLmethod

W42

CANNABINOID DETECTION WIPES

(Delta 8, 9, 10, THC & more)



WHAT CAN W42 WIPES DETECT

Cannabinoids including

Delta 8

Delta 9

Delta 10

THC

CBD

THC-A

THC-V

THC-O



WHAT FORMS CAN W42 WIPES TEST

Powders

Pills

Liquids

Residues

Trace

Bulk

Plant Material

Vaporizer Mouthpieces

Oils



COLOR-CHANGING TECHNOLOGY

When W42 comes in contact with cannabinoids, a deep **purple** color reaction indicates cannabinoids may be present.

Positive-result color **matches the packaging color** for quick field verification.



KNOWN FALSE POSITIVES

Rosemary extracts and some plant-based essential oils may produce false positive results.



RESULTS IN SECONDS



TRUSTED BY LAW ENFORCEMENT



OPEN. WIPE. LOOK. #OWLmethod



MADE IN USA



Note: The Trace Eye-D kit is intended to be used for presumptive identification purposes only, and all substances tested should be subjected to more definitive examination by scientists in a properly equipped crime laboratory.

W42

DRUG
DETECTION
WIPES



Directions | #OWLmethod

► OPEN pouch and remove wipe.

Do not unfold towlette before or after use - doing so may result in difficulty observing the results.

► WIPE it across the surface to be tested.

For best results, sample small amounts of the substance on the outer edge of the wipe.

► LOOK to see if the wipe has changed color.

Most results are instant, however, some may take up to 30 seconds for a color reaction to develop.

- Negative Result: NO color change
- Positive Result: Deep Purple



Positive Results

Positive test results indicated in the color above.

W42 Detects:

- Δ8 THC
- Δ9 THC
- Δ10 THC
- THCA
- THCV
- THC-O

MADE IN THE **USA**

FOR PATENT INFORMATION VISIT:
www.trace-eye-d.com/patents



Manufactured By Trace-Eye-D, LLC
573 Interstate Blvd., Sarasota, Florida 34240
866-TRACE91 | contact@traceeyed.com

TRACE-EYE-D.COM

WARNING!
SUFFOCATION HAZARD.
Not intended for children.



8 50050 94835 3



TRACE-EYE-D.COM



866.872.2391



INFO@TRACEEYED.COM



MADE IN USA | 100% AMERICAN-OWNED. ★

W42

DIRECTIONS

#OWLmethod



PPE ADVISORY

Reduce cross-contamination by wearing industry-standard personal protective equipment (PPE) such as nitrile gloves and eye protection.

1



ACTIVATE + OPEN

TO ACTIVATE, fold bottom portion of pouch in half. Squeeze folded portion until you hear a “pop” sound. Work the fluid from upper chamber to lower chamber.

OPEN the pouch and remove the wipe.

Do not unfold towelette before or after use.

Doing so may make results difficult to observe.

2



WIPE

it across the surface to be tested. For best results, sample very small amounts of the substance on the margin of the wipe.

3



LOOK

to see if the wipe changes color. Most results are instant, however, some may take up to 30 seconds for a color reaction to develop.



NEGATIVE RESULT

NO color change



POSITIVE RESULT

DEEP PURPLE



Color change is on a gradient from a pale green to a deep purple.



Note: For maximum shelf life keep product refrigerated.



TRACE-EYE-D.COM



866.872.2391



INFO@TRACEEYED.COM



MADE IN USA

100% AMERICAN-OWNED. ★

1

PHOTOGRAPH + STORE

the wipe with a date/time stamp, if required for evidence retention, as the color of the wipe may change over time.

2

DISPOSE

of wipe in accordance with federal, state, and local environmental laws. No neutralization is required. Can be disposed of in the **common waste stream**.

3

**WASH HANDS +
CHANGE GLOVES**

before conducting additional tests after a positive result is found.

**DISPOSAL NOTE**

All TRACE EYE-D products are safe for disposal in the **common waste stream** without neutralization or other special treatment, provided the wipe is not contaminated with drug residue.



NO NEUTRALIZATION REQUIRED
SAFE FOR DISPOSAL IN THE
COMMON WASTE STREAM.



Note: The Trace Eye-D kit is intended to be used for presumptive identification purposes only, and all substances tested should be subjected to more definitive examination by scientists in a properly equipped crime laboratory.

TRACE-EYE-D.COM

866.872.2391

INFO@TRACEEYED.COM